

INTERPHONE INSTRUCTIONS

There are only four buttons that you need to consider (Volume + and -, Reset/Off and the Interphone button).

To turn on and connect two (V6) units:

Start with both V6 units turned off. (Press the RESET button to turn off)

On both units simultaneously, press and hold the INTERPHONE button until the LED flashes red and blue continuously. Release the INTERPHONE buttons when you see both units flashing red and blue.


On the first unit, press the INTERPHONE button. The LED will flash blue as it seeks to pair with the other. Wait for 5-10 seconds, after which time the LED on the other unit should also start to flash blue.

Press the INTERPHONE button again on the first unit to set the communication channel between the two units.

Adjust the volume (+/-) as necessary

When finished, turn off the units by pressing the RESET/OFF button

If you press one of the other buttons during a match, you may lose the communication channel between the two units, although the connection should still remain. You should be able to recover communication by either pressing the INTERPHONE button again, or by pressing the green telephone button (if that was the one that was pressed)



Headsets

The Jabra Wave headset is connected to the Interphone via the 3.5mm audio socket. It **must** be connected using the small adapter cable supplied (only one adapter cable though !). The eargel can be rotated through 180 degrees to allow you to wear the headset in either right or left ear.

The acoustic air tube earpiece should also be connected to the interphone with an adapter. The earpiece can be rotated through 180 degrees to fit in either ear.




Charging the Interphone

A full charge should last approximately 6-7 hours. Charge using the supplied USB – 3.5mm cable, plugging into a PC USB socket, car or wall charger.

Charging should take approximately 1-2 hours, during which time the LED will show red. When charged, the LED goes out.

Do not leave the interphones for long periods of time (> 6 weeks) between use and charge as this can damage the rechargeable battery.

To connect THREE units, using the coach (V4) interphone.



Reset the pairings

Start with the V4 (Coach) unit

Press and hold the INTERPHONE/ON button until the LED flashes blue

Reset any existing pairing by pressing and holding both A and B buttons until the LED flashes red before switching to flashing blue.

Connect the first pair

Press and hold button A on the V4 unit whilst at the same time press and hold the INTERPHONE button on the V6 (umpire) unit until the LED on both units are flashing red and blue continuously.

Press button A on the V4 unit - the LED on the V4 unit will flash blue as it seeks to pair with the V6 unit. When the units have paired, both units will flash blue. When this occurs, briefly press button A on the V4 unit to switch to talk mode.

Press the 'OFF' button to turn the V4 unit off.

Connect the third unit

Turn the V4 unit back on by pressing and holding the INTERPHONE/ON button until the LED flashes blue

Press and hold button B on the V4 unit whilst at the same time press and hold the INTERPHONE button on the second V6 unit until the LED on both units are flashing red and blue continuously.

Press button B on the V4 unit - the LED on the V4 unit will flash blue as it seeks to pair with the V6. When the units have paired, both units will flash blue. When this occurs, briefly press button B on the V4 unit to switch to talk mode.

Enable three-way connection

Now press the A button on the V4 unit and three-way talk and listen should be enabled.